



PIONEER®
The future of sound and vision.

Service Manual

**ORDER NO.
ARP1483**

SPEAKER SYSTEM

S-Z91 XD
S-Z71 XD

PARTS LIST OF PACKING

Mark	Part No.	Description
	BHG-071	Packing case (For S-Z71)
	BHG-070	Packing case (For S-Z91)
	BHA-030	Protector (For S-Z71)
	BHA-029	Protector (For S-Z91)
	BRB-086	Operating guide (For S-Z71)
	BRB-085	Operating guide (For S-Z91)

PIONEER ELECTRONIC CORPORATION 4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153, Japan
PIONEER ELECTRONICS SERVICE INC. P.O. Box 1760, Long Beach, California 90801 U.S.A.
PIONEER ELECTRONICS OF CANADA, INC. 505 Cochrane Drive, Markham, Ontario L3R 8E3 Canada
PIONEER ELECTRONIC [EUROPE] N.V. Keetberglaan 1, 2740 Beveren, Belgium
PIONEER ELECTRONICS AUSTRALIA PTY. LTD. 178-184 Boundary Road, Braeside, Victoria 3195, Australia TEL: [03] 580-9911

MA © FEB. 1988 Printed in Japan

PARTS LIST OF EXPLODED

NOTES:

- Parts without part number cannot be supplied.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- For your Parts Stock Control, the fast moving items are indicated with the marks $\star\star$ and \star .
 $\star\star$ GENERALLY MOVES FASTER THAN \star
 This classification shall be adjusted by each distributor because it depends on model number, temperature, humidity, etc.
- Parts marked by "⊙" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

Parts List


Mark	Parts No.	Description
	BXB-065	Grille (For S-Z71)
	BXB-064	Grille (For S-Z91)
	BDD-003	CS cord (For S-Z71)
	FRKX-001	Input terminal (For S-Z91)
$\star\star$	E20EC65-53E	Woofer (For S-Z71)
$\star\star$	E20EC75-53E	Woofer (For S-Z91)
$\star\star$	P66AP45-57F	Tweeter (For S-Z71)
$\star\star$	P66AP45-58F	Tweeter (For S-Z91)
$\star\star$	E77CP60-62F	Mid-range (For S-Z91)

Mark	Part No.	Description
	BW4.2 x 16	Screw
⊙	BWN-034	Network assembly (For S-Z71)
⊙	BWN-033	Network assembly (For S-Z91)

NETWORK AND PARTS LIST

Circuit Diagram


⊙ Network Assembly (S-Z91)



Parts List (S-Z91)

Mark	Symbol & Description	Part No.
	L1 Chock coil (2.2 mH)	
	L2 Coil (0.47 mH)	
	C1 Capacitor (5.6 μF)	
	C2 Capacitor (3.3 μF)	
	R1 Resistor (4.7 Ω)	

⊙ Network Assembly (S-Z71)



Parts List (S-Z71)

Mark	Symbol & Description	Part No.
	L1 Chock coil (1.5 mH)	
	L2 Coil (0.47 mH)	
	C1 Capacitor (2.7 μF)	